

# Removable Disk Drive Kit WC56xx, WC57xx, WC75xx

Easily remove the disk drive for storage in a safe or locked cabinet.



---

**Available on:**

WC5665, WC5675, WC5687

WC5735, WC5740, WC5745, WC5755

WC5765, WC5775, WC5790

WC7425, WC7428, WC7435, WC7440

WC7525, WC7530, WC7535, WC7545, WC7556



The **Removable Hard Drive Kit** allows the printer administrator to easily remove the disk drive for storage in a safe or locked cabinet.

- The kit provides a means to relocate the printer's disk drive to an external location attached to the machine.
- The Disk drive is kept secure inside a lockable disk caddy attached to the back of the printer or attached shelf.
- Extra caddies with disk drive are available for purchase. Extra disk drives allow different users or departments to control their own disk drive.

**Notes:**

- The FAX option cannot be installed with this kit
- A disk drive is not included with the kit. The Xerox technician installing the kit will utilize the disk drive in the printer
- A hard disk drive is included with each optional caddy
- 4-6 weeks lead time (after an approved order)

**Security Disclaimer:** The configuration described above does not, in and of itself, provide any specific level of security required for the processing of US Government classified materials. The customer must establish such operation procedures as may be deemed necessary to ensure compliance with the applicable security regulations, as defined by the site security officer. The customer shall accept all responsibility for the accountability, proper handling and safeguarding of classified materials.

July 2011

Contact Customized Applications Service

[CAS@xerox.com](mailto:CAS@xerox.com)

585-427-5414