



## Recommended Xerox Media for Phaser 6280N, 6280DN, 6180N and 6180DN EUROPE

### Revision 2.0, February 2009

Last Revision: February 2007

#### Important Note:

All media is listed by product, Paper Type System Setting, Paper Type, weight (standard gsm), re-order number, size, and tray runability. The additional information column is for hints and tips on how to run certain media applications.

Media recommendations made in this publication are based on qualification tests\* conducted using standard test images with moderate to heavy image area coverage. Test duration for each product/media type is based on the suggested machine monthly copy/print volume. Test machines are maintained within specifications defined by user documentation.

\* Testing environment Temperature 20 degreesC±4, Relative Humidity 40% ±10%.








\* Machine reliability specifications may be affected by increased usage of the Transparency, Card Stock, Label, and Special modes. In addition, variances in machine reliability may occur due to extended use of some media types. Your Xerox service representative can advise you on special application media types for long duration copy/print runs.

For specifications and a description of the various media types discussed in this publication, please refer to [www.Xerox.com](http://www.Xerox.com).

For additional recommended Phaser media, look under Supplies on: <http://www.office.xerox.com/> and select your Product Family.

© 2007 Xerox Corporation. All rights reserved.

Xerox®, The Document Company®, and all Xerox product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.








Plain Paper		Glossy Paper	
Thin Card		Thick Glossy Paper	
Thick Card		Transparency	
Label			

Recommended Xerox Media for  
Phaser 6280N, 6280DN, 6180N,  
6180DN  
Europe revision 2.0 Feb 2009

A=Auto Duplex  
M=Manual Duplex  
S=Simplex Only



Paper	Paper Type	Weight	Re-Order #	Cross Reference #	Type	Size	Trays			Additional Information
							1	2	3	
Xerox Digital Colour Colotech+ (Gold Label)	Plain	90 gsm	3R97988			A4	A	A	A	Paper Type <i>Plain Paper</i> should be selected on the user interface for Trays or Printer Driver.
	Plain	100 gsm	3R97993			A4	A	A	A	
	Plain	120 gsm	3R97958			A4	A	A	A	
	Thin Card	160 gsm	3R97963			A4	A	A	A	Paper Type <i>Thin Card Stock</i> should be selected on the user interface for Trays or Printer Driver.
	Thick Card	200 gsm	3R97967			A4	M	M	M	Paper Type <i>Thick Card Stock</i> should be selected on the user interface Trays or Printer Driver. Environmental condition may require that this product be fed one sheet at a time.
	Thick Card	220 gsm	3R97971			A4	M	M	M	
Xerox Colour Impressions	Plain	90 gsm	003R97663			A4	A	A	A	Paper Type <i>Plain Paper</i> should be selected on the user interface for Trays or Printer Driver.
Xerox Business	Plain	80 gsm	003R91820			A4	A	A	A	
Xerox Premier	Plain	80 gsm	003R91720			A4	A	A	A	
Xerox Performer	Plain	80 gsm	003R90649			A4	A	A	A	
Xerox Recycled	Plain	80 gsm	003R91165			A4	A	A	A	
						A4	A	A	A	

Plain Paper		Glossy Paper	
Thin Card		Thick Glossy Paper	
Thick Card			
Label		Transparency	

Recommended Xerox Media for  
Phaser 6280N, 6280DN, 6180N,  
6180DN  
Europe revision 2.0 Feb 2009

A=Auto Duplex  
M=Manual Duplex  
S=Simplex Only



Paper	Paper Type	Weight	Re-Order #	Cross Reference #	Type	Size	Trays	Additional Information
Xerox Digital Colour Colotech+ Gloss	Glossy Coated	140gsm	3R97577			A4	A A A	Paper Type <i>Glossy Paper</i> should be selected on the user interface Trays or Printer Driver.
	Thick Glossy	210gsm	3R97583			A4	M M M	Paper Type <i>Thick Glossy Paper</i> should be selected on the user interface for Trays or Printer Driver. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints.
Xerox Trifold Brochures	Thick Card	176 gsm	3R97946			A4	M M M	Paper Type <i>Thick Card Stock</i> should be selected on the user interface Trays or Printer Driver.
Xerox Premium Business Cards	Thick Card	195gsm	3R97512			A4	M M M	
Xerox Colour Laser Labels	Label		003R93872			1 up A4	S S S	Paper Type <i>Labels</i> should be selected on the user interface for Trays or Printer Driver.
			003R93874			8 up A4	S S S	
			003R93875			14 up A4	S S S	
Xerox Universal Transparency 115 micron	Transparency		003R98220			A4	S	Paper Type <i>Transparency</i> should be selected on the user interface for Tray or Printer Driver. It is not recommended to output more than 20 transparencies at a time.

#### WARRANTY DISCLAIMER

Xerox makes no guarantees or warranties, either express or implied, concerning the performance, use or replacement of non-Xerox branded media or throughput products. Customers should inquire directly of their paper distributor or manufacturer for any guarantees they may offer. When purchasing a particular media product for the first time, customers are advised to purchase small quantities to insure that their expectations are met.

The quality of Xerox supplies is consistent from ream to ream, carton to carton, and it is backed by a Xerox 100% guarantee. The quality of non-Xerox branded paper may vary from ream to ream or carton to carton, so for optimum performance on Xerox color equipment, use only the best—Xerox Supplies.

© 2007 Xerox Corporation. All rights reserved.

Xerox®, The Document Company®, the stylized X®, and all Xerox product names and product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.