

# Recommended Xerox Media for Phaser 6250/B, 6250/N, 6250/DP, 6250/DT, and 6250/DX (USA and Canada)

For use in the US and Canada

Revision 2.0, Publish Date: June 1, 2005

For the most recent version of this quarterly published document, visit [www.xdss.com](http://www.xdss.com), select "Free Downloads", then "Color".

## Important Notes:

All media is listed by product, machine run mode, weight (standard gsm), re-order number, size, and tray runability. The additional information column is for hints and tips on how to run certain media applications.

Media recommendations made in this publication are based on qualification tests\* conducted using standard test images with moderate to heavy image area coverage. Test duration for each product/media type is based on the suggested machine monthly copy/print volume. Test machines are maintained within specifications defined by user documentation.

\* Testing Environment temperature range of 60-75 deg. F, Relative Humidity range 20-40%.

\*Machine reliability specifications may be affected by increased usage of the Transparency, Card Stock, Label, and Special modes. In addition, variances in machine reliability may occur due to extended use of some media types. Your Xerox service representative can advise you on special application media types for long duration copy/print runs.

For specifications and a description of the various media types discussed in this publication, please refer to [www.Xerox.com](http://www.Xerox.com).

For additional recommended Phaser media, look under Supplies on: <http://www.office.xerox.com/> and select your Product Family.

© 2004 Xerox Corporation. All rights reserved.

Xerox®, The Document Company®, the stylized X®, and all Xerox product names and product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.

Plain	Thick Card
Glossy Coated	Business Card
Thin Card	Label
Heavy Plain	Transparency

**Phaser 6250B, 6250N,  
6250DP, 6250DT, and  
6250DX**

A=Auto Duplex  
 M=Manual Duplex  
 S=Simplex Only

Paper	Paper Type	Weight	Re-Order #	Cross Reference #	Type	Size	Trays				Additional Information
							1/MPT	2	3	4	
Xerox Premium Multipurpose 4024	Plain	75gsm/ 20lb Bond	3R721			8.5 x 11	A	A	A	A	Refer to the "Paper Tips" embedded page for additional printer-specific information, e.g., High Capacity tray usage.
			3R727			8.5 x 14	A	A	A	A	
Xerox Business Multipurpose 4200	Plain	75gsm/ 20lb Bond	3R2047			8.5 x 11	A	A	A	A	Paper Type Plain should be selected on the user interface for Trays/MPT.
			3R2051			8.5 x 14	A	A	A	A	
Xerox Digital Color Xpressions+	Heavy Plain	90gsm/ 24lb Bond	3R11380			8.5 x 11	A	A	A	A	Paper Type Heavy Plain should be selected on the user interface for Trays/MPT.
			3R11382			8.5 x 14	A	A	A	A	
	Heavy Plain	120gsm/ 32lb Bond	3R11387			8.5 x 11	A	A	A	A	Paper Type Heavy Plain should be selected on the user interface for Trays/MPT.
Xerox Digital Color Elite Gloss	Thin Card	163gsm/ 60lb Cover	3R11390			8.5 x 11	A	A	A	A	Paper Type Thin Card should be selected on the user interface for Trays/MPT.
	Thin Card	120gsm/ 80lb Text	3R11450			8.5 x 11	A	A	A	A	Paper Type Thin Card should be selected on the user interface. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints.
	Glossy Coated	140gsm/ 100lb Text	3R11454			8.5 x 11	A	A	A	A	Paper Type Glossy Coated Paper should be selected on the user interface. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints.
Xerox Glossy Coated Paper	Glossy Coated	148gsm/ 100lb	3R11458			8.5 x 11	M				Paper Type Thick Card should be selected on the user interface. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints.
			3R12512	016-1704-00		8.5 x 11	A	A	A	A	Paper Type Glossy Coated Paper should be selected on the user interface. Environmental condition may require that this product be fed one sheet at a time. Gloss variation can occur from machine rolls, especially on high area coverage prints.
Xerox Postcard	Thick Card	176gsm/ 65lb Cover	3R12507	103R01016		8.5 x 11	M				Paper Type Thick Card should be selected on the user interface for Tray1/MPT.
Xerox Trifold Brochures	Thick Card	176gsm/ 65lb Cover	3R12508	103R01018		8.5 x 11	M				Paper Type Thick Card should be selected on the user interface for Tray1/MPT.
Xerox Premium Business Cards	Business Card	190gsm	3R12321	016-1898-00		8.5 x 11	M				Paper Type Business Card should be selected on the user interface for Tray1/MPT.

Plain	Thick Card
Glossy Coated	Business Card
Thin Card	Heavy Plain
Label	Transparency

**Phaser 6250B, 6250N,  
6250DP, 6250DT, and  
6250DX**

A=Auto Duplex  
 M=Manual Duplex  
 S=Simplex Only

Paper	Paper Type	Weight	Re-Order #	Cross Reference #	Type	Size	Trays				Additional Information
							1/MPT	2	3	4	
Xerox Premium Color Printing Paper	Heavy Plain	90gsm/ 24lb Bond	3R12509	016-1368-00		8.5 x 11	A	A	A	A	Refer to the "Paper Tips" embedded page for additional printer-specific information, e.g., High Capacity tray usage.
Xerox Digital Color Duradocument	Heavy Plain	100gsm/ 27lb Bond	3R12314	103R01020		8.5 x 11	S	S	S	S	Paper Type Heavy Plain should be selected on the user interface for Trays/MPT.
Xerox Laser/Ink Jet Labels	Label		3R12050		1 up	8.5 x 11	S				Paper Type Labels should be selected on the user interface for Trays/MPT.
			3R12051		8 up	8.5 x 11	S				
			3R12052		10 up	8.5 x 11	S				
			3R12053		14 up	8.5 x 11	S				
			3R12054		20 up	8.5 x 11	S				
			3R12055		24 up	8.5 x 11	S				
			3R12056		30 up	8.5 x 11	S				
	3R12057		33 up	8.5 x 11	S						
Xerox Digital Color Clear Transparency	Transparency		3R12502	016-1948-00		8.5 x 11	S	S			Paper Type Transparency should be selected on the user interface for trays/MPT. It is not recommended to output more than 20 transparencies at a time.

**WARRANTY DISCLAIMER**  
 Xerox makes no guarantees or warranties, either express or implied, concerning the performance, use or replacement of non-Xerox branded media or throughput products. Customers should inquire directly of their paper distributor or manufacturer for any guarantees they may offer. When purchasing a particular media product for the first time, customers are advised to purchase small quantities to insure that their expectations are met.

The quality of Xerox supplies is consistent from ream to ream, carton to carton, and it is backed by a Xerox 100% guarantee. The quality of non-Xerox branded paper may vary from ream to ream or carton to carton, so for optimum performance on Xerox color equipment, use only the best--Xerox Supplies. To learn more about the benefits of using Xerox Supplies, please contact your Supply Account Manager or call, in the US 1-800-822-2200 and in Canada 1-800-668-0199 (English) or 1-800-668-0133 (Francais).

© 2004 Xerox Corporation. All rights reserved.

Xerox®, The Document Company®, the stylized X®, and all Xerox product names and product names and product numbers mentioned in this publication are trademarks of Xerox Corporation. Other company trademarks are also acknowledged.