

Xerox DocuColor 242 / 252 / 260 North America Custom Materials List October, 2009

The Xerox CUSTOM Media List contains custom media that has been tested on the Xerox DocuColor 242 / 252 / 260 for image quality and performance. Custom media on this list are digitally optimized, designed and manufactured for performance in Xerox digital printing equipment. Best Practices for Operation are outlined below. Customers should validate the Best Practices for Operation are acceptable for their application.

Any alterations to the product's basic design, including sheet size, must be tested and approved by the Xerox Media & Compatibles Technology Center.

When purchasing a particular media product for the first time, customers are advised to purchase small quantities to insure that expectations are met. CUSTOM media may be ordered through the Xerox Supply Account Manager.

Plain/Recycled (64-105gsm)		Coated 1 (106-176gsm)		
Heavyweight 1 (106-176gsm)		Coated 2 (177-220gsm)		
Heavyweight 2 (176-220gsm)		Coated 3 (221-300gsm)		
Heavyweight 3 (221-300gsm)		Label		
Transparency		Transfer Paper		

Paper types are selected within System Settings

CML
DC 242/252/260
North America
September 2008 V 0.1

A=Auto Duplex
S=Simplex Only
M=Manual Duplex
PCW=Post Consumer Waste
ECF=Elemental Chlorine Free

Media	Mode	Image Quality System Setting	Weight	Re-Order #	Size	Trays 1 - 4				Tray 6		Tray 5 (Bypass)
						1	2	3	4	HCF	OHCF	5
Xerox SportsPix	Coated 2		280 gsm	Contact your local Supplies representative	8.5 x 11							S
Xerox FunFlip	Heavyweight 2	HW2D	280 gsm	Contact your local Supplies representative	8.5 x 11							S
Xerox Accordion Pix	Heavyweight 2	HW2C	215 gsm	Contact your local Supplies representative	8.5 x 11							M
Xerox Everflat	Coated 2		220 gsm	Contact your local Supplies representative	8.5 x 11 (portrait, landscape) 13 x 13							M
Xerox Premium Digital Carbonless Paper 8.5 x 11 (Singles)	Plain	Plain A	75 gsm/ 20lb	3R12434	CB Singles White	S	S	S	S	S	S	S
				3R12435	CFB Singles White	S	S	S	S	S	S	S
				3R12437	CFB Singles Canary	S	S	S	S	S	S	S
				3R12438	CB Singles Canary	S	S	S	S	S	S	S
				3R12439	CF Singles Pink	S	S	S	S	S	S	S
3R12440	CF Singles White	S	S	S	S	S	S	S				
Xerox Premium Digital Carbonless Paper 8.5 x 11 (2-Part)	Plain	Plain A	75 gsm/ 20lb	3R12420	2-Part White / Canary	S	S	S	S	S	S	S
				3R12421	2-Part White / Pink	S	S	S	S	S	S	S
Xerox Premium Digital Carbonless Paper 8.5 x 11 (3-Part)	Plain	Plain A	75 gsm/ 20lb	3R12424	3-Part Reverse P/C/W	S	S	S	S	S	S	S
				3R12425	3-Part Straight W/C/P	S	S	S	S	S	S	S

Additional Information

<p>1. Deletions or color variation may occur when overprinting perforations, die-cuts, and scores.</p> <p>2. Printing 3-5 mm beyond the edge of the perforation on all four sides will ensure the best image alignment.</p> <p>3. Unload output tray every 10-20 sheets</p> <p>4. Keep sheets in original packaging when storing or not in use.</p> <p>5. Carefully fan all sheets before loading into the paper tray.</p> <p>6. Do not fill the tray beyond the Fill Line</p> <p>7. For template and design layout, go to www.xerox.com/supplies</p>
<p>Short Edge Feed only. Select Face-up delivery.</p> <p>1. Deletions or color variation may occur when overprinting perforations, die-cuts, and scores.</p> <p>2. Printing 3-5 mm beyond the edge of the perforation on all four sides will ensure the best image alignment.</p> <p>3. Unload output tray every 10-20 sheets</p> <p>4. Keep sheets in original packaging when storing or not in use.</p> <p>5. Carefully fan all sheets before loading into the paper tray.</p> <p>6. Do not fill the tray beyond the Fill Line</p> <p>7. For template and design layout, go to www.xerox.com/supplies</p>
<p>Short Edge Feed only. Select Face-up delivery.</p> <p>1. Deletions or color variation may occur when overprinting perforations, die-cuts, and scores.</p> <p>2. Printing 3-5 mm beyond the edge of the perforation on all four sides will ensure the best image alignment.</p> <p>3. Unload output tray every 10-20 sheets</p> <p>4. Keep sheets in original packaging when storing or not in use.</p> <p>5. Carefully fan all sheets before loading into the paper tray.</p> <p>6. Do not fill the tray beyond the Fill Line</p> <p>7. For template and design layout, go to www.xerox.com/supplies</p>
<p>1. Hinge / Spine should always be run in the trailing edge orientation. This may require adjustment / rotation of the image file.</p> <p>2. Set Output delivery to Face Up orientation.</p> <p>3. Do not image over the recessed hinge.</p> <p>4. Deletions may be visible on output imaged in close proximity to the hinge / spine.</p> <p>5. Carefully fan all sheets before loading into the paper tray.</p> <p>6. Do not fill the tray beyond the Fill Line.</p>
<p>Carbonless Paper is not intended as sole application of machine.</p> <p>Limit Monthly usage to less than 5% of Monthly Print Volume (Approx. 1000 sheets).</p> <p>Use a machine with Offset Catch Tray rather than finishing devices if possible to minimize the risk of paper jams.</p> <p>Face up delivery is required.</p>